



To install handle, as your facing front of feeder with the chute and gate that slides up and down. Slide tip of handle with large hole in it thru the hole on the angle bracket on the left side until large hole is lined up with large hole on gate. Also make sure that the holes on the attached bracket line up to holes on front left angle piece. Using Large bolt and washers provided, bolt thru handle and gate so that they are bolted together. Do Not Over Tighten because this point needs to rotate. Next, bolt the bracket to the front left angle piece using hardware provided. At this time you should be able to operate gate slide up and down by pressing down on end of handle and letting it raise back up to close.



